



Acid Descaler / Milkstone Removal



WASH

1. Wash outside of cluster and attach cluster to jetters. Remove milk filter.



RINSE

2. Rinse plant with 10-15 litres of cold or warm clean water per cluster.



CLEANING PREPARATION SOLUTION

3. Make up the acid solution using an approved acid detergent at the recommended rate in hot water (75°C to 80°C) allowing 10-15 litres of solution per cluster.
Note: some acid detergents can be used cold with increased circulation time.



CLEANING

4. For hot solution circulate for 8-10 minutes and then run to drain.
For cold solution circulate for 10-15 minutes and then run to drain.



RINSE

5. Rinse plant with 10-15 litres of cold, clean water per cluster.



CHECK

6. Ensure the milk lines are completely drained before milking.

